

Automated Spiral Welding System for Bore, Flange and Valve Repair

The Climax BW1000 AutoBoreWelder is an automated spiral welding system that provides high quality bore welding technology in a ruggedly constructed, highly portable and easily affordable package.

Now you can:

- Increase both your welding and machining productivity.
- Dramatically reduce repair time and costs.
- Repair equipment on-site.
- Maximize equipment uptime.
- Extend the working life of your capital equipment.

Lightweight & Portable:

- Weighs just 17 lb (7.7 kg).
- Easy to transport from the shop to the field.

Extremely Versatile & Easy to Operate:

- Welds in any axis: vertical, horizontal or inverted.
- Operation is extremely simple.
- Interfaces with most wire feeders.



One setup for Both Welding & Boring:

The Climax Bore Welder Interface Kit simplifies your boring and welding setup process:


- Allows quick attachment of the BW1000 AutoBoreWelder directly to the Climax BB3000, BB4500 or BB5000 Boring System mounting fixtures.
- Ensures perfect alignment for both welding and machining.
- One setup for both welding and boring saves time, and helps you get your job done quickly.

Weld & Bore at the Same Time:

Because the BW1000 AutoBoreWelder uses the same mounting fixtures as the Climax BB3000, BB4500 or BB5000 Boring Systems, you can weld up one section of your job and bore out another section at the same time. Simply use an extra set of bearing mounts to line bore one set of bores while bore welding another...cuts your work time!

SPECIFICATIONS, WELD RANGE INFO

	US	Metric
Axial feed per revolution:	8TPI – 0.125 inch	8TPI – 3.3 mm
Welding process:	MIG (GMAW)	
Axial travel:	9.0 inch	228.6 mm
Wire diameter range:	0.030 - 0.045 inch	0.76 - 1.14 mm
Amperage rating:	140 A Continuous	
Length of standard pkg extension arms:	1 each: 3, 6, and 12 inch arms	1 each, 76.2, 152.4, and 304.8 mm arms
Max. reach without support:	40 inches	101.6 mm
Standard package torches:	Swivel #1, Swivel #2	
Torch range:	2.75 to 12 inches	69.9 to 304.8 mm
Power Supply Requirements:	120 VAC 50/60Hz or 230 VAC 50/60Hz, 175 Amp Rating CV power source (power supply not included in AutoBoreWelder 1000 System package).	



TOOL CONFIGURATIONS

Configure your BW1000 AutoBoreWelder in ten easy steps.

To configure your BW1000 AutoBoreWelder:

- 1 Select a Base Unit
- 2 Select a Swivel Torch Assembly
- 3 Select Swivel Torch Options
- 4 Select Additional Swivel Torch Consumables
- 5 Select a Standard Torch Adapter
- 6 Select Standard Torches
- 7 Select Standard Torch Consumables
- 8 Select Additional Torch Extensions
- 9 Select a Mounting Option
- 10 Select a Conduit Assembly

To configure the AutoBoreWelder you require, simply select the option you need in each step, then contact your Climax representative.

1 Base Unit	
Tool Kit ,Weld Head 9 inch (228.6 mm) Stroke, Rod, Collar, Standard Torch Extension Kit, Consumable Package, Power Cord, Radial Mount, Liner & Pelican Case	70198
2 Swivel Torch Assembly	
Swivel Assembly	35603
3 Swivel Torch Options	
Swivel Torch #1, 2.75 to 8.2 inch (70.0 to 208.0 mm) Dia.	39725
Swivel Torch #2, 8 to 12 inch (203.0 to 305.0 mm) Dia.	39726
Swivel Torch Kit #1 & #2 2.75 to 12 inch (69.9 to 304.8 mm) Dia.	70200
4 Swivel Torch Consumables	
Welding Tip 0.035 inch (0.9 mm)	69865
Welding Nozzle, Standard (For All Torches Except #0 & #00)	69866
Welding Diffuser	69778
5 Standard Torch Adapter (Swivel to Standard)	
Torch Adapter, Standard Torches to Swivel Assembly	33804
Small Bore Kit 0.88 to 3 inch (22.4 to 76.2 mm), Includes Standard Torch Adapter	36750
6 Standard Torches	
(Must have torch adapter or small bore kit)	
Torch bearing clearance package 12 to 27 inch (304.8 to 685.8 mm)	63916
#00 Torch (requires torch adapter, standard to swivel) Size range: 0.88 - 1.8 inches (22 - 46 mm) dia.	29063
#0 Torch (requires torch adapter, standard to swivel) Size range: 1.75 - 3 inches (44 - 76 mm) dia.	28448
#1 Torch (requires torch adapter, standard to swivel) Size range: 2.75 - 5.5 inches (70 - 139 mm) dia.	29064
#2 Torch (requires torch adapter, standard to swivel) Size range: 4.5 - 7.5 inches (114.3 - 190.5 mm) dia.	29032
#3 Torch (requires torch adapter, standard to swivel) Size range: 6 - 9 inches (152 - 228 mm) dia.	29033
#4 Torch (requires torch adapter, standard to swivel) Size range: 8-11 inches (203.2 - 279.4 mm) dia.	29034
#5 Torch (requires torch adapter, standard to swivel) Size range: 10 - 13 inches (254 - 330 mm) dia.	29035
#6 Torch (requires torch adapter, standard to swivel & torch counterbalance) Size range: 12 - 15 inch (304.8 - 381.0 mm) dia.	31792
#7 Torch (requires torch adapter, standard to swivel & torch counterbalance) Size range: 14 - 17 inches (356 - 432 mm) dia.	31792

6 Standard Torches, continued	
#8 Torch (requires torch adapter, standard to swivel & torch counterbalance) Size range: 16 - 19 inch (406.4 - 482.6 mm) dia.	31792
#9 Torch (requires torch adapter, standard to swivel & torch counterbalance) Size range: 18 - 21 inches (457 - 533 mm) dia.	30710
Trammel OD torch package up to 14 inch (355.6 mm) dia.	27013
Trammel torch 28 inch (711.2 mm) maximum OD capability Torch counterbalance	38506 30756

7 Standard Torch Consumables	
Welding tip #00, 0.035 inch (0.9 mm)	69521
Welding tip #00, SPEZ Feed 0.045 inch (1.2 mm)	69554
Welding tip #0, Standard 0.035 inch (0.9 mm)	69520
Welding tip #0, Large Radius 0.035 inch (0.9 mm)	67997
Welding tip #0, Standard Radius 0.045 inch (1.2 mm)	68622
Welding tip #0, SPEZ Feed 0.045 inch (1.2 mm)	69555
Welding tip, 0.035 inch (0.9 mm)	69865
Welding tip, 0.045 inch (1.2 mm)	70149
Welding tip, 0.030 inch (0.8 mm)	70150
Welding tip, 0.035 inch (0.9 mm) Chromium/Zirconium	62642
Welding tip #00, 0.035 inch (0.9 mm) Chromium/Zirconium	69891
Welding Tip #0, Standard 0.035 inch (0.9 mm) Chromium/Zirconium	70204
Welding Tip 0.045 inch (1.2 mm) Dia. Chromium/Zirconium	70205
Welding Nozzle (For All Torches Except #00 & #0)	69866

8 Additional Torch Extensions	
Torch Extension Kit 3 to 18 inch (76.2 - 457.2 mm), Includes 3, 6, 12 & 18 inch (76.2, 152.4, 304.8 & 457.2 mm)	69895
Torch Extension 3 inch (76.2 mm)	29038
Torch Extension 6 inch (152.4 mm)	29039
Torch Extension 12 inch (304.8 mm)	29040
Torch Extension 18 inch (457.2 mm)	29065
Torch Extension Support	40877

9 Mounting Options	
Adjustable Base	29037
Adapter Kit to BB3000 1-1/4 inch (31.8 mm) Bar	26795
Adapter Kit to BB4500 1-3/4 inch (44.5 mm) Bar	43731
Adapter Kit to BB5000 2-1/4 inch (57.2 mm) Bar	26518
Tool Alignment for BB3000 1-1/4 inch (31.8 mm) Bar	26656
Tool Alignment for BB4500 1-3/4 inch (44.5 mm) Bar	36062
Radial Mount 5 inch (127.0 mm), Radius Standard Spacer	28208
Radial Mount 10 inch (254.0 mm), Radius Spacer	35006
Weld Head Support Rod	30773
Mounting Rod Extender	30831

10 Conduit Assembly	
Conduit Switch Assembly for Miller	37688
Conduit Switch Assembly for Euro	36862
Conduit Switch Assembly for Tweco	39408
Conduit Switch Assembly for Lincoln	43071
Conduit Switch Assembly for Hobart & Thermal Arc Hefty II	69282

CLIMAX GLOBAL LEARNING CENTER

Climax has been teaching the fundamentals and fine points of portable machine tool operation for practically as long as we've been inventing and building the tools.

At the Global Learning Center situated in our corporate headquarters near Portland, Oregon, we provide training for machine tool operators on portable machine tool safety and machine setup and operation. Trainees also receive technical tips and tools to improve operational efficiencies, with the vast majority of every program devoted to hands-on activities and skill development.

The Climax instructional team includes specialists in shipbuilding, power generation, civil engineering, bridge re-building, petrochemical and other industries.



Whether it's a regularly scheduled course at the Global Learning Center, or custom curriculum conducted at your facility, your machinists will benefit from courses developed by some of the most respected authorities in the business.

Call us today to register for a regularly scheduled class, or talk to us about how we can customize a training program for your specialized application.

Call Climax for:

On-site Training

Need some refresher courses in setting up and operating your Climax machine tool?


Special Projects

Climax has been solving complicated on-site machining and welding problems for our customers since 1964.

Rentals

With 16 worldwide rental depot locations, you are never far away from a Climax portable machine tool.

Climax Global Locations



Connect with us: [f](#) [t](#) [in](#) [g+](#)

World Headquarters

2712 E. Second Street
Newberg, Oregon 97132 USA
Worldwide Telephone: 1.503.538.2185
N. America Toll-Free: 1.800.333.8311
Fax: 1.503.538.7600
Email: info@cpmt.com

European Headquarters

Am Langen Graben 8
52353 Düren, Germany
Telephone: (+49) (0) 2421.9177.0
Fax: (+49) (0) 2421.9177.29
Email: info@cpmt.de

Copyright © 2013 Climax Portable Machining & Welding Systems. All Rights Reserved. Climax has taken reasonable measures to ensure the accuracy of the information contained in this document. However, Climax makes no warranties or representations with respect to the information contained herein; and Climax shall not be held liable for damages resulting from any errors or omissions herein, or from the use of the information contained in this document.

 **CLIMAX**
Portable Machining & Welding Systems